

IMPORTANT

WHEN FREEZING WEATHER CONDITIONS ARE LIKELY, IT IS IMPORTANT TO PROTECT THE HIGH PRESSURE PUMP FROM FROST DAMAGE.

EITHER:

STORE THE UNIT INDOORS WHERE THE TEMPERATURE REMAINS ABOVE FREEZING.

RUN A MILD ANTI-FREEZE SOLUTION THROUGH THE PUMP VIA THE WATER SUPPLY HOSE (OR SEPARATE HOSE IF BOWSER MOUNTED).

IF USING THIS METHOD ENSURE ALL ANTI-FREEZE SOLUTION IS WASHED THROUGH PUMP ON COMMENCEMENT OF WORK TO AVOID DAMAGING PAINTWORK OR SENSITIVE AREAS.

OR:

AFTER USE, DISCONNECT THE WATER SUPPLY AND RUN THE MACHINE FOR APPROXIMATELY 15 SECONDS UNTIL WATER STOPS COMING FROM PUMP.

IF IN ANY DOUBT, DO NOT START THE MACHINE AS DAMAGE MAY OCCUR.